



LIGHTING THE WOOD BURNERS

- Only burn dry wood in the wood burner. We have provided smaller pieces of wood cut to the correct size; this can be replenished for a small charge if you run out. Please do not burn any pieces that you have gathered from the woods
- The air control is the circular wheel in the centre of the bottom door, open this about 1cm by turning it anti-clockwise
- Place a firelighter on the grate and then cover with several pieces of kindling
- Light the firelighter and leave the door ajar for a few minutes
- Once the fire starts to draw, place two or three pieces of wood on top
- Close the door and once the wood is burning, partially close the primary air control on the bottom door
- Refuel the fire with more wood as needed but don't over fill as it will cause excess smoking, usually re-fuelling needs to be done every 45-60 minutes. After re-fuelling open the air vents fully to get the wood lit as quickly as possible. Once lit reduce the air intake again
- Adjust the air control to achieve the desired burning rate; flames should still be seen flickering rather than the wood just smouldering
- Open the door slowly to prevent smoke escaping into the room. Don't operate the wood burner with the door left open
- Wood burns best when lying on a small bed of ash. If the stove has been left smouldering for a while it is best to burn it vigorously for a short while to burn off any unwanted deposits
- We advise you to allow the burner to go out overnight, do not attempt to remove any hot ash from the stove

enquiries@wildwithnature.co.uk

01953 525325

www.wildwithnature.co.uk

Manor Farm, Rocklands Road, Shropham, Norfolk, NR17 1DX